

Original HP Media InkJet

September 2017

Western Europe



HP InkJet Printers	HP Everyday Photo Paper		HP Advanced Photo Paper				HP Premium Plus Photo Paper				HP Iron-on Transfers	HP Social Media Snapshots	HP Professional Paper			HP PageWide Bro GLSC Paper		HP ZINK® Sticky-backed Photo Paper	
	A4	10 x 15	10 x 15	13 x 18	A4	A3	10 x 15	13 x 18	A4	A3	A4	10 x 13	A4 120 g	A3 120 g	A4 180 g	A3 180 g	A4	A3	5 x 7.6
	Q5451A Q2510A	CR757A	Q8691A Q8008A Q8692A	Q8696A	Q5456A Q8698A	Q8697A	CR677A CR695A	CR676A	CR673A CR674A CR672A	CR675A	C6050A	W2G60A	Q6593A	Q6594A	Q6592A C6818A	C6821A	Z7567A	Z7568A	W4Z13A 1DE37A
HP DeskJet																			
HP DeskJet F370/F375/F380/F390																			
HP DeskJet 450ci/450cbl/450wbt																			
HP DeskJet 460c/cbl/wbt/wf																			
HP DeskJet 5440																			
HP DeskJet 710c/720c/722c/815c																			
HP DeskJet 810c																			
HP DeskJet 820cxi/850c/870cxi																			
HP DeskJet 816c/825c/840c/843c/845c																			
HP DeskJet 880c/890c/895cxi																			
HP DeskJet 916c/920c/940c/ HP Colour Copier 310																			
HP Colour Copier 290																			
HP DeskJet 930c/cm/950c/959c																			
HP DeskJet 960c/970cxi/980cxi/990cxi/cm/995c																			
HP DeskJet 1000/1050/1050se/2000/1515AiO/ 2050/2050se/ 3000/3050/3050se/3050ve																			
HP DeskJet 1010/1050A/1510AiO/1512/1514/2050A/2054A/ 2540 e-AiO/2542/2544/2549/3050A/3052A/3054A																			
HP DeskJet 2510/2514/3055A /3057/3059																			
HP DeskJet 3070A																			
HP DeskJet 1100c/1120c/1125c																			
HP DeskJet 1200c/ps																			
HP DeskJet 1180c/1220c/1220c/ps/1280																			
HP DeskJet 1600c/cm																			
HP DeskJet 2130																			
HP DeskJet 3320/3325/3420/3425 series																			
HP DeskJet 3520 e-AiO																			
HP DeskJet 3520/3535/3550/3745																			
HP DeskJet 3645/3647/3650/3845																			
HP DeskJet 3810/3816/3820/3822 series																			
HP DeskJet 3920/3940																			
HP DeskJet 5145/5150/5151/5550/5552																			
HP DeskJet 5650/5652/5655																			
HP DeskJet 5740/5745																			
HP DeskJet 5850																			
HP DeskJet 5940																			
HP DeskJet 6122/6127																			
HP DeskJet 6520/6540/6540d/6620/6840/9800/9800d																			
HP DeskJet 6940/6980																			
HP DeskJet 9300																			
HP DeskJet 9650/9670/9680/9680gp																			
HP DeskJet D1360/D1460/D1470/D1560																			
HP DeskJet D2330/D2360/D2430/D2460																			
HP DeskJet D1660/D2560/D2660/D5560																			
HP DeskJet D4160/D4260/D4360																			
HP DeskJet F2180/F2187/F2280/F2290																			
HP DeskJet F2224																			
HP DeskJet F2420/F2480/F2492/F4140/F4172/ F4180/F4190/F4210/F4212/F4280/F4580																			
HP DeskJet F4224																			
HP DeskJet Ink Advantage F735																			
HP DeskJet Ink Advantage (K209g)																			
HP DeskJet Ink Advantage 2060 K110																			
HP DeskJet Ink Advantage 1515AiO/1516/2515/2645AiO/2646/3515 e-AiO																			
HP DeskJet Ink Advantage 3525/4615/4625 e-AiO/5525/6525																			
HP OfficeJet																			
HP Fax 3180																			
HP Digital Copier 410																			
HP 910 InkJet Printer																			
HP CopyJet/M																			
HP Colour InkJet CP 1700 series/																			
HP Business InkJet 2600 series																			
HP Business InkJet 1000 series																			
HP Business InkJet 1100 series																			
HP Business InkJet 1200 series																			
HP Business InkJet 2200 series/2300 series																			
HP Business InkJet 2800 series																			
HP Business InkJet 3000																			
HP OfficeJet t45/t65/r45/r65																			
HP OfficeJet g55/g85/g95/k60/k80																			
HP OfficeJet Pro 1150c																			
HP OfficeJet Pro 1170c/1175c																			
HP OfficeJet Pro 251dw/276dw																			
HP OfficeJet 6000/6500/7000 series																			
HP OfficeJet Pro 6230 ePrinter/6830 e-AiO																			
HP OfficeJet 6500A/6500A Plus																			
HP OfficeJet 7100 WF ePrinter/7500A WF																			
HP OfficeJet Pro 8000/8500 series/8500A/8500A Plus																			
HP OfficeJet 3630/J3680/3830																			
HP OfficeJet 4105/4110/4212/4215/4219/4252/4255/4315/4355																			
HP OfficeJet 4500 G510 a/g/h																			
HP OfficeJet 4620/4622 e-AiO																			
HP OfficeJet 2620/2622/2624 AiO/4630/4634/4636 e-AiO																			
HP OfficeJet 4650																			
HP OfficeJet Pro X451 dw/X551 dw/X476 dw MFP/X576 dw MFP																			
HP OfficeJet H470/b/wbt/100 mobile/150 mobile																			
HP OfficeJet J4524/J4535/J4580/J4624/J4660/J4680																			
HP OfficeJet 5110/30/v40/v45/ HP PSC 750/950/HP Fax 1230																			
HP OfficeJet 5505/5510/5515																			
HP OfficeJet 5605/5607/5610/5615																			

HP InkJet Printers	HP Everyday Photo Paper		HP Advanced Photo Paper				HP Premium Plus Photo Paper				HP Iron-on Transfers	HP Social Media Snapshots	HP Professional Paper				HP PageWide Bro GLSC Paper		HP ZINK® Sticky-backed Photo Paper	
	A4	10 x 15	10 x 15	13 x 18	A4	A3	10 x 15	13 x 18	A4	A3	A4	10 x 13	A4 120 g	A3 120 g	A4 180 g	A3 180 g	A4	A3	5 x 7.6	
	Q5451A Q2510A	CR757A	Q8691A Q8008A Q8692A	Q8696A	Q5456A Q8698A	Q8697A	CR677A CR695A	CR676A	CR673A CR674A CR672A	CR675A	C6050A	W2G60A	Q6593A	Q6594A	Q6592A C6818A	C6821A	Z7567A	Z7568A	W4213A 1DE37A	
HP OfficeJet J5730/J5780/J5785/J6410/J6415/J6424
HP OfficeJet 5740 e-AiO
HP OfficeJet 6100 ePrinter/6600 e-AiO/6700 Premium e-AiO
HP OfficeJet 6110
HP OfficeJet 6205/6210/6215
HP OfficeJet 6310/6315
HP OfficeJet K7100
HP OfficeJet 7210
HP OfficeJet 7310/7410
HP OfficeJet Pro 8210/8218
HP OfficeJet Pro 8710/8715/8718/8719
HP OfficeJet Pro 8720/8725/8730/8740
HP OfficeJet Pro 7740 WF
HP OfficeJet 7100 WF ePrinter/7510 WF/7610 WF eAI0/7612 WF
HP OfficeJet 9100 series
HP OfficeJet Pro K550/K5400
HP OfficeJet Pro L7480/L7580/L7590/L7680/L7780/K8600
HP OfficeJet Pro K850 series
HP OfficeJet Pro 8600 E-AiO/8600 Plus e-AiO/8610/8615/8620
HP OfficeJet Pro 8100 e-Printer (N811a)
HP PageWide Pro 352dn/377dn/452dw/477dw
HP PageWide Pro 452dw/477dw
HP Photosmart
HP PSC 500
HP PSC 1100/1200/1205
HP PSC 1210/1213/1215/1217/1219
HP PSC 1310/1311/1312/1315/1315s/1317
HP PSC 1340/1350/1355
HP PSC 1402/1410/1415/1417
HP PSC 1507
HP PSC 1510/ HP PSC 1510s/ HP DeskJet 1510
HP PSC 1600/1610
HP PSC 2105/2108/2110/2115/2171/2175/2179/2210
HP PSC 2350/2355/2355p
HP PSC 2410/2510
HP Fax 1220
HP Photosmart 100/130/230
HP Photosmart 145/245
HP Photosmart 325/335/375/385/422/428/475
HP Photosmart A310/A314/A320/A432/A433/A436/ A440/A441/A444/A516/A526
HP Photosmart A532/A612/A618/A626/A636/A646/A717/A826
HP Photosmart 1000/1100/1115/1215/1218/1315
HP Photosmart 2570
HP Photosmart 2575
HP Photosmart 2610/2710
HP Photosmart 3110/3210/3310/D6160/D7160/D7260/D7360/D7460
HP Photosmart C3170/C3175/C3180/C3190/C4180/C4190
HP Photosmart C4205/C4270/C4272/C4280/C4340/C4380/C4390/C4424/ C4472/C4480/C4485/C4524/C4580/C4585/C4599
HP Photosmart C4670/C4680/C4685/C4780
HP Photosmart C5180/C6180/C6270/C6280/C6285/ C7180/C7280/C8180
HP Photosmart C5280/C5288
HP Photosmart C5324/C5380/C6324/C6380/D5460
HP Photosmart D5160
HP Photosmart D5360
HP Photosmart e-AiO 5520/6520
HP Photosmart e-AiO 5510/5515/6510
HP Photosmart 7150/7260/7345/7350/7450/7459/7550/7655
HP Photosmart 7510 e-AiO
HP Photosmart 7520 e-AiO
HP Photosmart 7660/7755/7760/7762/7960/7960gp
HP Photosmart 7850
HP Photosmart 8050
HP Photosmart 8150/8450/8450gp
HP Photosmart 8250
HP Photosmart 8750/8750gp
HP Photosmart Pro B8350
HP Photosmart B8550
HP Photosmart Pro B9180/B8850
HP Photosmart e-Station C510a
HP Photosmart B010a/B109a/B109d/B109f
HP Photosmart Wireless B109n/B110a/c/e
HP Photosmart Plus B209a/B209c/B210a/c
HP Photosmart Premium C309n/g/C310a
HP Photosmart Premium Fax C309a/C410b
HP Photosmart Ink Advantage K510a
HP ENVY
HP ENVY 100 D410a
HP ENVY 110 e-AiO
HP ENVY 120 e-AiO
HP ENVY 4500/4502/4504/5530/5532 e-AiO printers
HP ENVY 4520
HP ENVY 5540 e-AiO
HP ENVY 5640 e-AiO
HP ENVY 7640 e-AiO
HP Sprocket Photo Printer***

* Use with the HP Social Media Snapshot App and wireless / AirPrint / Google Print Plugin capable InkJet printers.
 ** For use with HP Sprocket Photo Printer only.
 *** HP Sprocket printer is only available in UK, Germany, Spain and Switzerland.

hp.com/go/learnaboutesupplies

© Copyright 2017 HP Development Company, L.P. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

4AA2-5925EEE, September 2017

This is an HP Indigo digital print.

